

Faux Bow™ 3.0

Assembly Instructions:

1. Take the two Lime Green Bow Limbs and snap them into place so it looks like the picture. Make sure the bow string is not tangled or wrapped around anything.

NOTE:
Make sure "Arrow Holder" Bow Limbs are on the top!


2. Screw "Launch Tube" onto bow end. For those that care... (reverse threads)

That's it!

Faux Bow™ 3.0

Shooting:

1. For best accuracy and distance, pull handle all the way back using your **middle two finger-tips only**. All you have to do is relax your fingers to fire your arrow.
2. **Do not shoot at anybody or any animal!**
Please play safely!



FAUX BOW™

Item # 61006

WARNING:
This product propels foam tipped arrows at a very high rate of speed. If an arrow hits someone at a close distance it will hurt a lot! It may even cause serious eye damage. Before shooting, make sure you are not aiming at anybody (including animals).
For ages 8 and up
Please Play Safely!!!

WARNING: CHOKING HAZARD
Small parts Not suitable for children under 3 years of age.

Customer service: 800-781-8110
©2017 Marky Sparky, Inc. All rights reserved
1230 Simpson Way Escondido, CA 92029

Color and parts may vary from those pictured.
www.markysparkytoys.com

This product contains no Phthalates or Lead.
It meets or exceeds ASTM and EN71 standards.